# PV Activity 4: Output vs. Light Wavelength (Color)©

- To investigate wavelength (color) of light on the PV cell output current.
- To answer the question of why fluorescent bulbs are more efficient than incandescent bulbs



#### **MATERIALS**

- PV Cell Module
- Electrical Leads
- DC ammeter
- DC voltmeter
- 2 Lamps
- Light Filters
- 60W Incandescent Bulb
- Compact Fluorescent Bulb (13W Comparable light to 60W Incandescent Bulb)

#### **OVERVIEW:**

This experiment is designed to look at the effect of wavelength (color) of light on the output of a solar cell. Using an incandescent light bulb, the current output of the solar cell is measured as a series of filters are placed over the solar cell. Next a florescent bulb is used as a light source and the experiment is repeated. Given a sunny period with fairly consistent sunlight, this experiment can be run outdoors using light from the sun. The ratio of the solar cell current output shaded by the filter to the output of the cell without a filter can be used to investigate the dependence of the solar cell output on wavelength. This information can also be used to evaluate the wavelength of light emitted by the source.

By Stanley Micklavzina, Asher Tuhman, and Frank Vignola for the **Meyer Fund for Sustainable Development** and the University of Oregon Department of Physics and the Solar Radiation Monitoring Laboratory

Page 4.1 6/20/2011

Name:	_ Kit #	Per

# Part I: Affects of wavelength ("color") on PV cell current output

# Use only one cell on the PV module in the following exercise.

PV cells response (current output) is dependent upon the wavelength of sunlight. This exercise investigates this wavelength dependence of the PV cell performance (output). Note that PV cells also respond to some Infrared (IR) irradiance, a spectral region of light that we cannot see.




Fig. 4.1: Measuring current from a solar cell.

This experiment will be performed

twice. First, use the lamp with an incandescent bulb and then with a lamp with a florescent bulb. It is suggest that two lamps be used, one with each type of bulb. This makes it unnecessary to unscrew the very hot incandescent bulb before screwing in the florescent bulb.

There is a graph on the page 4.3 that shows the transmittance curves for the light filters.

- Connect one cell and current meter to measure the short circuit current of the cell (see Fig. 4.1). Be sure to keep the light source at a constant distance throughout the measurements.
- Cover the PV cell with the various color filters provided and record the current. (Note: The black piece of plastic actually blocks visible light and passes Infrared.(IR). The "clear" filter passes most of the visible light but blocks some of the IR.)
- 3. Repeat step 2 with the lamp with the fluorescent bulb.
- 4. Calculate the % of current coming from the various wavelengths of light: % Current Output = (Filter Current/No Filter Current) x 100

**Table 4.1:**. Effect of Color (Wavelength) on Cell Current using a Desk Lamp

Color of Filter	Current (A)	Incandescent	Current (A)	Fluorescent
	Incandescent	Percent of	Compact	Percent of
	Bulb	<b>Current Output</b>	Fluorescent	<b>Current Output</b>
No filter		100%		100%
Yellow				
Fire Red				
Red				
Blue				
Black Plastic (IR Pass)				
Clear (Block IR)				
Black Plastic + Clear.				


Name:	Kit #	Per.

#### FILTER PROPERTIES

Table 4.2: Wavelengths being transmitted by the filters

Color of Filter	Wavelength being Transmitted
Yellow (Blocks Blue Light)	> 500nm
Fire Red (Blocks Blue and some green)	>550nm (color Filter # 15)
Red (Blocks blue and green)	> 630nm (color Filter # 27)
Cerulean Blue (Blocks most red)	See Fig. 4.3
Black Plastic (Passes Infrared Blocks all visible)	> 780nm
Clear Filter (Blocks Infrared Passes Visible	< 800nm

Ideally, the combination of the Black Plastic filter and the Clear filter would cause the current to go to zero. It does not go to zero because the Clear filter does not block all the Infrared irradiance from passing through the filter. The combination of the Blue and the Red filter act very much like the Black Plastic Filter except they block a little more of the infrared radiation because each transmits only 90% of the IR.



Figures 4.2 & 4.3: Percent transmission of the filters.




Fig. 4.4: Spectral distribution of lamps




Fig. 4.5: Solar spectrum on 9/2/2010

Name:	_ Kit #	Per	
Discuss your results and include answers to the following questions.			
What part of the light spectrum has produced or Infrared (IR)? (You can observe the table digraph % Current Output vs. Wavelength for the Blocking filters.)	ata or a suggested analy	sis would be to	
Why is the current output form the PV cell less the illumination is about the same?	ss for the Compact Fluore	escent bulb while	
Why are Compact Fluorescent bulbs replacing households?	រូ Incandescent bulbs in b	usinesses and	

Name:		Kit #	Per	
Part II: Effect of sur	Part II: Effect of sunlight on PV cell output current			
Repeat the experiment with sunlight and see what you find.  Note percent transmittance is equal to the current with the filter divided by the current without a filter times 100.				
	Color (Wavelength) o	_	unlight	
Color of Filter	Current (A)	Percent		
Nia Ciltan	Sunlight	Transmitted		
No filter Yellow		100%		
Fire Red				
Red				
Blue				
Black Plastic (IR				
Pass)				
Clear (Block IR)				
Black Plastic +				
Clear.				
			ı	
<b>Discuss your results below.</b> What part of the solar spectrum seems to have the greatest effect on the solar cell, Visible or IR?				
How does the sun output compare with the light bulbs?				

Compare and contrast the effects of the filters when the sun is the light source and when the light comes from the incandescent bulb and the florescent bulb. Is it possible

to tell if the incandescent light bulb has a larger percentage of IR radiation than

sunlight?

Name:	Kit #	Per.

### **Instructors Note:**

If the students would plot % Output vs. Wavelength they would get data like seen below. The Y axis is the percent of output compared to the unfiltered output and the x axis is the wavelength that starts transmission through the filter (Table 4.2)

This shows most of the energy is actually coming from the IR part of the spectrum and not the visible part of the spectrum.

